



Reservdelslista sprängsskiss A			escowa
Sorgente Vattenkylare			
ES5227	2020-09-07		
v1.2	A3	F. Friberg	
1	ES1461 Displaykort Sorgente		
2	ES1981 Etikett touchpanel Sorgente		
3	ES1982 Front displaykort Sorgente		
4	ES1984 Spillbricka Sorgente		
5	ES1983 Galler Spillbricka sorgente		
6	ES1893 Kabel mellan display/mainboard		
7	ES1387 Flottör Till Smile/Omni Spillbricka		
8	ES1989 Front Till Sorgente		
9	ES1988 Sidopanel Vänster Till Sorgente		
10	ES1987 Sidopanel Höger Till Sorgente		
11	ES1986 Panel Övre Till Sorgente		



Reservdelsslita sprängsskiss B			escowa
Sorgente Vattenkylare			
ES5227	2020-09-07		
v1.2	A3	F. Friberg	
1	ES1585 Filter Inline Omni		
2	ES1134 Hållare För Inline Filter		
3	ES1650 Insticksvinkel 1/4"-1/4" (Vit)		
4	ES1653 Insticksvinkel 6 mm - 6 mm (Svart)		
5	ES1689 Låsclip 1/4"		
6	ES1309 Co2 Klocka Engångsflaska Smile/Omni		
7	9924 Kolsyra 600 Gram Engångsflaska		
8	ES1458 Fläkt Till Smile/Omni		
9	ES1465 Pump Till Smile/Omni (2010)		
10	ES1462 Mainboard Till Smile/Omni Co2/Naturell Touch		
11	ES1468 Y-Koppling Inkommande Ventil Smile Touch		
12	ES1481 Ventil Inkommande Till Smile Touch		
13	ES2232 Skottgenomgång Till Smile/Omni		
14	ES1472 Tempsensor Till Smile/Omni Touch		
15	ES1463 Ventil 5-vägs Smile/Omni 2010		
16	ES1473 Utloppspip Smile/Omni		
17	ES1973 Vinkelkoppling pump Smile/Omni		
18	ES1655 Strålsamlare neopearl		



Reservdelistsa sprängsskiss C			escowa
Sorgente Vattenkylare			
ES5227	2020-09-07		
v1.2	A3	F. Friberg	
1	ES1472 Tempsensor Till Smile/Omni Touch		
2	ES1675 O-Ring Till JG Koppling 5/16		
3	ES1474 Säkerhetsventil Smile/Omni		
4	ES1477 Snabbkoppling Orange Till Smile/Omni Touch		
5	ES1478 Snabbkoppling Vit Till Smile/Omni Touch		
6	ES1479 Snabbkoppling Blå Till Smile/Omni Touch		
7	ES1476 Snabbkoppling Lila Till Smile/Omni Touch		
8	ES1480 Snabbkoppling Grön Till Smile/Omni Touch		
9	ES1471 Backventil Till Karbonator Smile/Omni Touch		
10	ES1475 Snabbkoppling Gul Till Smile/Omni Touch		